




**SMARA**  
CURATIONS  
*Crafting Memories*



### Control panel



1. -/+ button for setting the cooking wattage and time.
2. Display for seeing the wattage and time.
3. Power ON button with light to turn the appliance on and off.
4. Timer to set the time manually as per the cooking requirements.
5. Manual button for manual cooking mode.
6. Seven cooking modes for preset wattage and time control.

## • Induction Cooktop BOROSIL SmartKook - 1600 W

Super quick heating due to high wattage

- 8 power levels to adjust cooking temperature to the perfect level
- energy efficient - no heat loss while cooking
- automatic off function saves energy
- no flame cooking makes for an enjoyable and cool experience
- auto pan detection
- digital led indicator
- push button controls
- live input voltage supply display system
- programmed to work even under conditions of voltage fluctuation
- 1 year warranty on borosil smart kook induction cooker - pc11